

Installing PrimeYield

Version B-2008.12, December 2008

SYNOPSYS®

Copyright Notice and Proprietary Information

Copyright © 2008 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

“This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of _____ and its employees. This is copy number _____.”

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Registered Trademarks (®)

Synopsys, AMPS, Astro, Behavior Extracting Synthesis Technology, Cadabra, CATS, Certify, Design Compiler, DesignWare, Formality, HDL Analyst, HSPICE, Identify, iN-Phase, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Physical Compiler, PrimeTime, SCOPE, Simply Better Results, SiVL, SNUG, SolvNet, Synplicity, the Synplicity logo, Synplify, Synplify Pro, Synthesis Constraints Optimization Environment, TetraMAX, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

Trademarks (™)

AFGen, Apollo, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, BEST, Columbia, Columbia-CE, Confirma, Cosmos, CosmosLE, CosmosScope, CRITIC, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, DesignPower, Direct Silicon Access, Discovery, Eclipse, Encore, EPIC, Galaxy, Galaxy Custom Designer, HANEX, HAPS HapsTrak, HDL Compiler, Hercules, Hierarchical Optimization Technology, High-performance ASIC Prototyping System, HSIM, HSIM^{plus}, i-Virtual Stepper, IICE, in-Sync, iN-Tandem, Jupiter, Jupiter-DP, JupiterXT, JupiterXT-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Rail, Mars-Xtalk, Milkyway, ModelSource, Module Compiler, MultiPoint, Physical Analyst, Planet, Planet-PL, Polaris, Power Compiler, Raphael, Saturn, Scirocco, Scirocco-i, Star-RCXT, Star-SimXT, System Compiler, System Designer, Taurus, TotalRecall, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

Service Marks (SM)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license.

ARM and AMBA are registered trademarks of ARM Limited.

Saber is a registered trademark of SabreMark Limited Partnership and is used under license.

All other product or company names may be trademarks of their respective owners.

Installing PrimeYield

This document describes how to install the PrimeYield product.

Note:

The installation instructions in this document are the most up-to-date available at the time of production. However, changes might have occurred. For the latest installation information, see the product release notes or documentation.

This document contains the following sections:

- [Media Availability and Supported Platforms](#)
- [Disk Space Requirements](#)
- [Installing the Software](#)
- [Setting Up the User Environment](#)
- [Verifying the Hercules Installation](#)
- [Viewing the PrimeYield Documentation](#)

To install Synopsys tools, it is recommended that you log on as root or have system administrator privileges. You need write permission for the installation directory.

Media Availability and Supported Platforms

The Hercules tool is available on CD or by EST. Obtain the appropriate binary executable files based on the operating system you need. Table 1 shows the supported platforms for the B-2008.09 release.

Installing PrimeYield

Disk Space Requirements

Note:

The PrimeYield software is configured so that multiple platforms of this version can be installed in a single installation directory (*install_dir*).

Table 1 Supported Operating Systems and Keywords

Platform	Operating System	Platform Keyword	Path Keyword
AMD Opteron	Red Hat Enterprise Linux v4, v5	amd64 (64-bit mode)	AMD.64
EM64T	SUSE Linux Enterprise 9, 10 ¹	suse32 (32-bit mode) suse64 (64-bit mode)	SUSE.32 SUSE.64
IA-32 (X86)	Red Hat Enterprise Linux v4, v5	linux (32-bit mode) ²	IA.32
Sun SPARC ³	Solaris 9, 10 ¹	sparc64 (64-bit mode)	SUN.64

1. Binary-compatible hardware platform or operating system. Note, however, that binary compatibility is not guaranteed. See <http://www.synopsys.com/products/platforms> for latest information.

2. The 32-bit (x86) and 64-bit (x86_64) Linux software is binary compatible with the Intel EM64T or AMD Opteron running Red Hat Enterprise Linux. See <http://www.synopsys.com/products/platforms> for latest information.

3. Available in January 2009.

Disk Space Requirements

Make sure you have enough disk space for PrimeYield and VUE installation. The disk space requirement varies depending on the platform and the tool selected for installation. Table 2 shows the maximum space required for installing each product on a particular platform

Table 2 Disk Space Requirements (in Megabytes)

Operating System	Megabytes
Platform-independent files (common files)	20
AMD 64-bit	529
SUSE 64-bit mode	408
32-bit mode	375
Red Hat Linux 32-bit mode	441

Table 2 Disk Space Requirements (in Megabytes) (Continued)

Operating System	Megabytes
Solaris 9, 10 64-bit mode	903

Installing the Software

Hercules uses the Synopsys Installer tool, which allows you to use a graphical user interface (GUI) or a text script. For information about downloading Synopsys Installer and Hercules, see *Installing Synopsys Tools*, available at <http://www.synopsys.com/install>.

To install Hercules by EST or from the CD, follow the procedures described in *Installing Synopsys Tools*. It shows an example Synopsys media installation script for the synthesis tools. Hercules is installed in a similar manner.

Hercules is a stand-alone product and cannot be installed over an existing Synopsys product, including a prior version of Hercules. You must create a new directory for Hercules.

Setting Up the User Environment

To set up the user environment, you must modify the `py_setup.csh` and `py_setup.sh` files and set the license environment variable.

Specifying the Executable File Location

Set the `$PRIMEYIELD_HOME_DIR` environment variable by replacing the `<TOP-LEVEL-INSTALL-DIR>` text in the `install_dir/py_setup.csh` and `install_dir/py_setup.sh` files with `install_dir`.

- If you are using the C shell, modify the following line:

```
setenv PRIMEYIELD_HOME_DIR <TOP-LEVEL-INSTALL-DIR>
```

For example,

```
setenv PRIMEYIELD_HOME_DIR /usr/synopsys/primeyield/version
```

- If you are using the Bourne shell, modify the following line:

Installing PrimeYield

Verifying the Hercules Installation

```
PRIMEYIELD_HOME_DIR=<TOP-LEVEL-INSTALL-DIR>
```

For example,

```
PRIMEYIELD_HOME_DIR=/usr/synopsys/primeyield/version
```

Setting the SNPSLMD_LICENSE_FILE or LM_LICENSE_FILE Environment Variable

You must install the SCL software and define the SNPSLMD_LICENSE_FILE, LM_LICENSE_FILE, or another tool-specific variable before you can verify the Hercules installation.

For information about downloading and installing SCL and on setting the license variable, see [Installing Synopsys Tools](#).

Verifying the Hercules Installation

To verify the Hercules installation,

1. Make sure you are in a directory where you have read/write privileges.

```
% cd $HOME
```

2. Invoke the tool by entering

```
% primeyield -v
```

If you see information about the product version, production date, and copyright, the installation was successful.

Viewing the PrimeYield Documentation

The PrimeYield documentation is in PRIMEYIELD_HOME_DIR/doc/primeyield. You will see several directories: the pdf directory contains PDF files of all PrimeYield user guide and reference manual documents, while the document-specific directories contain HTML versions of these documents.

The documentation is available

- through the VUE Help menu.
- from the Synopsys web site SolvNet Online Support.

The release notes are available on SolvNet in the Download Center.